



## Repair Parts List and Diagram for DryRod Type 10B Series Ovens

**WHEN ORDERING, SPECIFY PART NUMBER, DESCRIPTION, QUANTITY AND THE FOLLOWING NAME-PLATE DATA, "TYPE, MODEL NO. & VOLTAGE"**

Item No.	Description		Qty/ Oven	Part No.			
				120V Models	240V Models		
1	Electrode Holder	Type 10B	Without Thermometer	1	1804600		
		Type 10BTH					
		Type 10BTL					
		Type 10BVT					
		Type 10B-E	With Thermometer (shown on page 1)			1	1252000
		Type 10BTH-E					
		Type 10BTL-E					
Type 10BVT-E							
<b>Cord Kit Includes</b>							
2	Cord Assembly with Grounding Plug - (Remove Plug on 240V Models)		1	1257120			
3	Strain Relief Bushing (7P-2)		1				
<b>Lead Kit includes material to make:</b>							
4	Wire Leads (set of 2) - Not used on type 10B & 10B-E		1	4109100			
5	Jumper Wire	Type 10BTH, 10BTH-E, 10BTL, & 10BTL-E	1	4109000			
6	Heating Element	Types 10B & 10B-E	100 Watt	1	4401601	4401603	
		Types 10BTL & 10BTL-E		1	4401601	4401603	
		Types 10BTH & 10BTH-E	150 Watt	1	4401602	4401604	
		Types 10BVT & 10BVT-E		1	4401602	4401604	
7	Indicator Light (with Wire Leads)		1	4601700	4601701		
8	Thermostat	Types 10BTH & 10BTH-E	1	4301900			
		Types 10BTL & 10BTL-E	1	4302000			
8A	Adjustable Thermostat	Types 10BVT & 10BVT-E	1	4302200			
9	Bottom		1	2611400			

