

IV. TYPE 50B & 50C REPAIR PARTS ILLUSTRATION

Item No.	Description	Part Numbers					
		Qty/ Oven	120V AC Only	Qty/ Oven	240V AC Only	Qty/ Oven	50C/120V AC/DC
1	Lid Assembly	1	NLA	1	NLA	1	NLA
1A	Lid Gasket (not shown)	1	NLA	1	NLA	1	NLA
2	Pull Catch Loop	1	7201400	1	7201400	1	7201400
3	Compartment Divider	2	2601000	2	2601000	2	2601000
4	Thermostat Kit	1	1257061	1	1257061	-	-
Lead Kit includes material to make:							
5	Wire Assembly (2 ring terminals)	1	1257123	1	1257123	1	1257123
6	Wire Assembly (2 female terminals)	-		1		-	
7	Wire Assembly (female terminal)	5		1		4	
8	Wire Assembly (2 female terminals)	-		1		-	
9	Fiberglass Sleeve 1.25 Ft.	1		1		1	
Cord Kit Includes							
10	Cord with Plug, remove plug for 240V	1	1257120	-	1257120	1	1257120
11	Strain Relief Bushing (7P-2)	1		1		1	
Heating Element Kit Includes							
12	Heating Element	2	NLA	2	NLA	2	NLA
13	Insulating Shield	2		2		2	

Note

Always replace BOTH heating elements if one fails. (Two are required for each oven.)
Replacement elements are sold in sets of (2) each only.

[CLICK HERE TO ORDER PARTS](#)

